


Quick start guide

For RS Models



**Follow
me!**



 **Robomow®**
friendly home


Watch
the
Video



Wire Setup





Carefully read and review all safety instructions, warnings and cautions contained in the Operating & Safety Manual.




1 Base Station Location

Chap. 1.1.4




2 Wire Direction & Distance

Chap. 2.1.2




3 Corners

Chap. 1.6.1, 2.2.1



4 Obstacles Inside Lawn

Chap. 1.6.1, 2.2.1



Hard obstacle


5 Multiple Zones & Narrow Pass

Chap. 1.3, 2.3




$W < 1.2m$

Chap. 1.2.2, 2.2.2




$1.2m < W < 2m$

Chap. 1.2.2



$2m < W < 5m$

Chap. 1.2.1



$W > 5m$

6 Finish




Connect the wire

Base Station Installation

7 Remove charging adaptor Chap. 2.6.3




8 Connect the wires Chap. 2.6.3




9 Assemble adaptor Chap. 2.6.3



10 Insert 2 stakes Chap. 2.7



Power Box Installation



Chap. 2.8

11



12



Connect 20m extension cable

13




One-Time Setup

14 Insert fuse Chap. 3.1




15 Follow instructions on Robomow LCD Chap. 3.3.1- 3.3.3



16 Setup complete



17 Add pegs



Reference

